

## ENGINE SERIAL NUMBER GUIDE

(Serial number of first engine built in year)

Engine	Serial Number Suffix	1972	1973	1974	1975
2-71	(2A)	85087	86279	88906	92258
3-71	(3A)	79536	80506	81772	83322
4-71	(4A)	175996	182907	192267	201395
6-71	(6A)	248936	272037	295884	317658
12-71	(12A)	7599	-	-	-
24-71	(24A)	568	-	-	-
2-53	(2D)	31648	-	-	-
3-53	(3D)	92337	103048	114363	126016
4-53	(4D)	81979	91891	104147	118187
6V-53	(6D)	84457	93545	104554	117870
8V-53	(8D)	5056	5779	6508	-
8.2	(8G)	-	-	-	-
12V-149	(12E)	1511	1797	2441	3308
16V-149	(16E)	258	406	2258	2715
6V-71	(6VA)	63698	68936	76103	83893
8V-71	(8VA)	164953	212755	263580	312998
12V-71	(12VA)	27217	31036	35732	42694
16V-71	(16VA)	7091	7696	8793	10414
6V-92	(6VF)	-	-	330	753
8V-92	(8VF)	-	-	608	3000
12V-92	(12VF)	-	-	-	-
16V-92	(16VF)	-	-	-	1014
3-53	(DB)*	-	-	-	-
4-53	(DB)*	-	-	-	-
6V-53	(DB)*	-	-	-	-

\* = Series 53 Brazilian engines

† = V71 Vauxhall Engines

**ENGINE SERIAL NUMBER GUIDE**

(Serial number of first engine built in year)

Engine	Serial Number Suffix	1972	1973	1974	1975
6V-71†	(6VW)	-	-	-	-
8V-71†	(8VW)	-	-	-	-

\* = Series 53 Brazilian engines

† = V71 Vauxhall Engines

**ENGINE SERIAL NUMBER GUIDE**

(Serial number of first engine built in year)

Engine	Serial Number Suffix	1976	1977	1978	1979
2-71	(2A)	96031	98179	99832	102060
3-71	(3A)	85360	86622	88356	91254
4-71	(4A)	211904	217942	226719	235791
6-71	(6A)	332518	346750	363474	383376
12-71	(12A)	-	-	-	-
24-71	(24A)	-	-	-	-
2-53	(2D)	-	-	-	-
3-53	(3D)	132996	140042	149459	156459
4-53	(4D)	130979	142705	153389	163134
6V-53	(6D)	137232	150301	164924	177379
8V-53	(8D)	-	6757 <i>W</i>	6779	-
8.2	(8G)	-	-	-	870
12V-149	(12E)	4136	4516	5118	5542
16V-149	(16E)	3388	3784	4325	5072
6V-71	(6VA)	90735	96214	102397	109395
8V-71	(8VA)	332778	352434	370909	387198
12V-71	(12VA)	47948	51768	56934	62224
16V-71	(16VA)	12225	13472	15078	16154
6V-92	(6VF)	1163	7597	21033	29536
8V-92	(8VF)	4398	8331	18770	34236
12V-92	(12VF)	-	-	-	603

(Serial number of first engine built in year)

Engine	Serial Number Suffix	1976	1977	1978	1979
16V-92	(16VF)	1149	1360	2033	2773
3-53	(DB)*	-	-	1631	4238
4-53	(DB)*	-	6103	30611	45568
6V-53	(DB)*	-	-	1501	6057
6V-71	(6VW)†	-	-	740	951
8V-71	(8VW)†	-	-	3496	4605

\* = 53 Brazilian engines

† = V-71 Vauxhall engines

### ENGINE SERIAL NUMBER GUIDE

(Serial number of first engine built in year)

Models	Serial Number Suffix	1980	1981	1982	1983
2-71	(2A)	103084	104064	105345	105938
3-71	(3A)	93850	96585	98903	99743
4-71	(4A)	244142	252368	260660	265225
6-71	(6A)	402393	414833	426666	431867
12-71	(12A)	-	-	-	-
24-71	(24A)	-	-	-	-
2-53	(2D)	-	-	-	-
3-53	(3D)	165142	173980	183686	187591
4-53	(4D)	173284	185204	197307	201552
6V-53	(6D)	189278	203804	213393	220648
8V-53	(8D)	-	-	-	-
8.2	(8G)	2380	26314	49621	67726
12V-149	(12E)	5902	6337	7807	8097
16V-149	(16E)	5546	6225	7070	7506
6V-71	(6VA)	114948	121419	127934	130333
8V-71	(8VA)	403649	414883	424827	429985
12V-71	(12VA)	66325	70811	75323	76898

\* = Brazilian engines

‡ = Last Unit built

† = V71 Vauxhall engines

**ENGINE SERIAL NUMBER GUIDE**  
(Serial number of first engine built in year)

Models	Serial Number Suffix	1980	1981	1982	1983
16V-71	(16VA)	16815	17665	18647	18997
6V-92	(6VF)	59288	75269	87940	98800
8V-92	(8VF)	56967	66994	75197	81446
12V-92	(12VF)	605	690	1079	1358
16V-92	(16VF)	3470	4517	5698	6060
3-53	(DB)*	5326‡	-	-	-
4-53	(DB)*	53632‡	-	-	-
6V-53	(DB)*	7186‡	-	-	-
6V-71	(6VW)†	1160	1691	-	-
8V-71	(8VW)†	5302	6023	-	-

\* = Brazilian engines

‡ = Last Unit built

† = V71 Vauxhall engines

**ENGINE SERIAL NUMBER GUIDE**  
(Serial number of first engine built in year)

Models	Serial Number Suffix	1984	1985	1986	1987
2-71	(2A)	106014	106114	106233	-
3-71	(3A)	100419	1010291	101386	101649
4-71	(4A)	283732	268457	273305	277157
6-71	(6A)	437367	444805	450007	454231
3-53	(3D)	192100	198002	201788	204163
4-53	(4D)	206188	211860	215845	218846
6-53	(6D)	226970	232563	237118	240091
8.2L	(8G)	90548	116572	145645	169919
8V-149	(8E)	2502	2516	2533	2554
12V-149	(12E)	8193	8596	8761	8878
16V-149	(16E)	7780	8288	8555	8800
S60	(6R)	-	-	46	641*

\* = Production engines began with 1000 numbers March of 1987.

All engine numbers less than 1000 were prototypes.

(Serial number of motor)

Models	Serial Number Suffix	1984	1985	1986	1987
6V-71	(6VA)	132764	134457	136777	138249
8V-71	(8VA)	433763	438112	441455	444781
12V-71	(12VA)	77992	79193	80439	81348
16V-71	(16VA)	19254	19438	19555	19691
6V-92	(6VF)	-	124769	138252	147899
8V-92	(8VF)	87677	99597	109240	116454
12V-92	(12VF)	1579	1854	2095	2418
16V-92	(16VF)	6184	6521	6728	6942

\* = Production engines began with 1000 numbers March of 1987.  
All engine numbers less than 1000 were prototypes.

## ENGINE SERIAL NUMBER GUIDE

(Serial number of first engine built in year)

Models	Serial Number Suffix	1988	1989	1990	1991
2-71	(2A)	-	-	-	-
3-71	(3A)	101790	102098	102380	102619
4-71	(4A)	278921	28125	283732	285367
6-71	(6A)	458175	461334	463867	466239
3-53	(3D)	205630	207447	208728	209719
4-53	(4D)	221369	223855	225902	227378
6V-53	(6D)	244387	247601	250817	253379
8.2L	(8G)	194394	214557	230813	300010
8V-149	(8E)	2594	2632	2654	2680
12V-149	(12E)	8962	9153	9376	9663
16V-149	(16E)	9026	9435	10037	10706
20V-149	(20E)	-	-	-	-
S60	(6R)	2489	7912	19370	36682
S50	(4R)	-	-	-	-
6V-71	(6VA)	139512	140642	141280	141688
8V-71	(8VA)	447118	449111	450085	451040
12V-71	(12VA)	82196	83332	84317	85241
16V-71	(16VA)	19767	19868	19974	20063
6V-92	(6VF)	157536	165978	176967	185719
8V-92	(8VF)	123521	130586	137828	143409
12V-92	(12VF)	2892	3683	4657	5645
16V-92	(16VF)	7376	7852	8624	9361

2-71	(2A)	-	102396
3-71	(3A)	102813	287128
4-71	(4A)	286290	469561
6-71	(6A)	467847	211669
3-53	(3D)	210623	229137
4-53	(4D)	228305	258413
6V-53	(6D)	256278	300269
DD 500	(8G)	300134	2784
8V-149	(8E)	2714	10130
12V-149	(12E)	9873	11592
16V-149	(16E)	11184	200020
20V-149	(20E)	200012	1359
S50	(4R)	1001	107892
S60	(6R)	67287	142478
6V-71	(6VA)	142124	452670
8V-71	(8VA)	452007	86899
12V-71	(12VA)	85948	20192
16V-71	(16VA)	20123	200371
6V-92	(6VF)	193422	155992
8V-92	(8VF)	150345	7609
12V-92	(12VF)	6641	10945
16V-92	(16VF)	10082	