

**Executive Order VR-102-A**

**Exhibit 1**

**Figure 1A**

**OPW Phase I Vapor Recovery System Equipment List**

<b>Component Name</b>		<b>Manufacturer</b>	<b>Model Number</b>
<b>Spill Containers and Covers</b> <sup>1</sup>	Figure 2E	OPW/POMECO	1-2100 Series 1C-2100 Series 1SC-2100 Series
<b>Replacement Drain Valve Kit</b>	Figure 2F	OPW	1DK-2100
<b>Gasket Seal Adaptor</b>	Figure 2G	OPW	FSA-400
<b>Rotatable Phase I Adaptors</b>	Figure 2H Figure 2I	OPW	61SALP-EVR (product) 61VSA-EVR (vapor)
<b>Installation Tool</b>	Figure 2J	OPW	61SA-Tool
<b>Dust Caps</b>	Figure 2K	OPW	634TT-EVR (product) 1711T-EVR (vapor)
<b>Drop Tube Overfill Prevention Device</b> <sup>2</sup>	Figure 2L	OPW	61SO-EVR Series
<b>Jack Screw Kit</b>	Figure 2M	OPW	61JSK-4400-EVR
<b>Tank Bottom Protector</b>	Figure 2N	OPW	6111-1400 (optional)
<b>Tank Gauge Port Components</b>	Figure 2O	Morrison Brothers	305XPA Series Tank Monitoring Cap and Ring Kit
<b>Pressure/Vacuum Vent Valve</b>	Figure 2P	Husky	Model 4885, 2-Inch Threaded

<sup>1</sup> The OPW/Pomeco 511 series covers include the 1-2100, 1C-2100 or 1SC-2100 spill containers.

<sup>2</sup> Ball float vent valves are not certified for installation of this system in new facilities (including those undergoing major modifications).