

California Environmental Protection Agency



ARB Approved

Installation, Operation and Maintenance Manual

for Executive Orders

VR-201-B

(Healy Phase II EVR System)

and

VR-202-B

(Healy Phase II EVR System Including
Veeder-Root In-Station Diagnostic (ISD) System)

Note:

Sections pertaining to the Veeder-Root ISD System will be posted only after VR-202-B has been signed by the Executive Officer.

NOTICE:

The ARB Approved Installation, Operation and Maintenance Manual describes the tools, method and skill levels required to install both the Healy Phase II EVR System Not Including ISD, ARB Executive Order VR-201-B and the Healy Phase II EVR System Including Veeder-Root ISD System, ARB Executive Order VR-202-B.

Unless specified otherwise, only skilled technicians that are trained, certified and licensed by Healy Systems, Inc. (i.e. Healy Certified Technicians) are able to perform installation, maintenance or repairs of components manufactured by Healy Systems, Inc. or warranty will be void.

It is the responsibility of each Healy Certified Technician to be familiar with the current requirements of state, federal and local codes for installation and repair of gasoline dispensing equipment.

It is also the responsibility of the Healy Certified Technician to be aware of all the necessary safety precautions and site safety requirements to assure a safe and trouble free installation.

Unless specified otherwise, only skilled technicians that are trained, certified and licensed by Veeder-Root are able to perform installation, maintenance or repairs of components manufactured by Veeder-Root, or warranty will be void.

It is the responsibility of each Veeder-Root technician to be familiar with the current requirements of state, federal and local codes for installation and repair of gasoline dispensing equipment.

It is also the responsibility of the Veeder-Root technician to be aware of all the necessary safety precautions and site safety requirements to assure a safe and trouble free installation.

Table of Contents

Healy Installation, Operation and Maintenance Manual¹

Component	Manufacturer/Model	Starts on Page
Scheduled Maintenance	Healy Phase II EVR System	1
Nozzle	Healy Model 900	10
Tank Pressure Management System	Healy Model 9961	20
Inverted Coaxial Hoses	Healy Model 75B Series	27
Hose Adaptors	Healy Model CX6 Series	30
Reconnectable Breakaway Couplings	Healy Model 8701VV	31
	Healy Model 807	34
Flow Limiters	Healy Model 1301	37
	Healy Model 1302	38
Pressure/Vacuum Vent Valve	Husky Model 4885	39
Dispensers with Vacuum Pump	Gilbarco Encore 300 & 500 Series with Healy Model VP1000	40
	Gilbarco GasBoy 9800 Series with Healy Model VP1000	64
	Wayne Harmony Series (Balance) with Healy Model VP1000	84
	Wayne Harmony Series (Assist) with Healy Model VP1000	103
	Wayne Ovation Series with Healy Model VP1000	123
	Wayne Vista Series with Healy Model VP1000	147

¹ All components listed on this page of the Table of Contents are applicable to both Executive Order VR-201-B (Healy Phase II EVR System Not Including ISD) and Executive Order VR-202-B (Healy Phase II EVR Systems with Veeder-Root ISD System).

Veeder-Root In-Station Diagnostics (ISD) Install, Setup, & Operation Guide and Manuals²

Veeder-Root ISD Install, Setup, & Operation Manual

Veeder-Root ISD Vapor Flow Meter Installation Manual

Veeder-Root ISD Pressure Sensor Installation Guide

² All components listed on this page of the Table of Contents are ONLY applicable to Executive Order VR-202-B (Healy Phase II EVR System with Veeder-Root ISD System).