

Modification Highlights for VR-201 and VR-202 Revision M

Executive Orders VR-201 and VR-202:

- Legal Language has been updated to reflect latest revision level, VR-201-M and VR-202-M.
- Document headers and footers on Exhibits 1-12 have been updated to reflect latest revision level, VR-201-M and VR-202-M.
- Under the legal language portion of both documents, the certification expiration date has been extended through September 1, 2011 to allow additional time to complete the renewal evaluation

Executive Order VR-202 Only:

- Exhibit 1, Page 25, ISD Software Version changed from 1.02 to 1.03.
- Exhibit 2, Page 20, added language that reads:

“Shutdown Control

The TLS Console must be wired per the Veeder-Root ISD Install, Setup and Operation Manual 557013-800, Rev. E of the ARB Approved Installation, Operation and Maintenance Manual for the Healy Phase II EVR System Including the Veeder-Root ISD System such that it shall automatically prohibit the dispensing of individual dispensers or through shutdown of all the gasoline turbine pumps during a CP-201 ISD failure alarm. It shall also automatically prohibit the dispensing of all dispensers during a TLS Console ISD system power loss.”

- Exhibit 2, Page 22, Figure 2B-7, ISD daily report illustration, software version changed from 1.02 to 1.03.
- Exhibit 9, Veeder-Root ISD Operability Test Procedures, Section 3.2 added, 4.1 modified, 5.3 modified and 8.1 modified to address the limited range of the ISD pressure sensor, when the vacuum exceeds -5 inches WC.
- Exhibit 10, FFS INCON ISD Operability Test, Page 9, amended the INCON ISD operability test procedure to include a test of the ISD vapor pressure sensor when exposed to UST pressure. This is in addition to the previously required ambient reference test.
- Exhibit 11, Section 4 (Equipment). The bulleted format has been eliminated to reflect a consistent format.

Installation, Operation and Maintenance Manual

The following changes were only made to IOM 20: Veeder-Root ISD Install, Setup, & Operation Manual:

- Page iii, Warranty updated to expand language from one paragraph to four. Add warranty language for components that are installed after initial ISD startup. Added language that requires a Warranty Registration and Checkout Form to be filed with Veeder-Root. Added additional liability language.
- Page 1-1, Site Requirements, bullet 4, to add dispenser relay boards for single dispenser shutdown.
- Page 1-3, Table 1-2, I/O manual added.
- Page 2-1, Installation equipment list, added Dispenser Relay Module.
- Page 2-3, Site Shutdown Requirements Updated for Dispenser Relay.
- Page 3-1, Alarm Setup updated for Dispenser Shutdown.
- Page 3-7, Figure 3-6 EVR/ISD Setup updated for Dispenser Shutdown.
- Page 3-8, Alarm Setup Introduction updated.
- Page 3-9, Figure 3-8 added.
- Page 3-10, Updated Figure 3-9 to note dispenser relay option.
- Page 3-11, Figure 3-10 description added.
- Page 3-12, Updated Figure 3-11 to note dispenser relay option.
- Page 3-13, Figure 3-12 description added.
- Page 3-14, Alarm Setup for Sites with Dispenser Relays added, Figure 3-13 added.
- Page 3-15, Figure 3-14 added.
- Page 6-1, added language concerning operator maintenance of paper and LED warning indicators of the TLS console.