



Investigation of solid particle number measurement: existence and nature of sub 23 nm particles under PMP methodology

Zhongqing Zheng, Kent C. Johnson, Thomas D. Durbin, and Heejung Jung College of Engineering, Center for Environmental Research and Technology (CE-CERT) University of California, Riverside

Shaohua Hu and Tao Huai California Air Resources Board (CARB)

David B. Kittelson


Department of Mechanical Engineering University of Minnesota





Typical diesel particle size distribution

Currently, diesel PM is regulated on a mass basis








Background

- Current gravimetric method
 - Difficulty quantifying particle mass emissions accurately
- Particle number method
 - The European Particle measurement program (PMP)
 - The PMP measures solid particles bigger than 23 nm
- Findings of previous PMP work
 - Sub 23 nm particles appearing-to-be solid present below PMP





Existence of sub 23 nm particles




What is the nature of these sub 23 nm particles downstream the PMP?





PMP schematic







Objective

Investigate the nature of the sub 23 nm particles downstream the PMP


Method


Compare the PMP system with another volatile particle remover – Catalytic Stripper (CS)





Catalytic Stripper (CS) schematic
















Test conditions

Base	CE-CERT HD Chassis dynamometer
Vehicle	Freightliner class 8
Engine	Caterpillar C-15 (14.6L)
Fuel	ULSD
Lubricating oil	SAE 15W-40
DPF	JM CRT
Vehicle weight	65,000 lb
Truck mileage	41442 miles
Cycles	(a) 56 mph cruise at 74% engine load; (b) 56 mph cruise at 26% engine load.





Experimental setup



Alternate between the APC and CS






Results






CVS particle size distribution








26% engine load






Integrated particle number emissions







CPC concentrations-74% load




APC showed higher concentration than the CS





CPC concentrations-74% load




CPCs with smaller cut off diameters showed higher concentration than CPCs with higher cut off diameters





CPC concentrations-26% load




Similar trend observed at 26% load



Number concentration (#/cc)



CPC concentrations-26% load




Difference between CPC 3025A and 3776 indicates: Particles are formed due to renucleation of semivolatiles downstream the PMP







APC ET temperature oscillation



College of Engineering- Center for Environmental Research & Technology











Conclusion

- Particle number emissions for both the PMP and CS were higher than the Euro VI HD limit at the 74% engine load and lower at the 26% engine load.
- Particle number concentrations between 3 and 10 nm downstream the APC were ~ 2 and 7 times higher than the number concentrations of particles above 10 nm at the 74 and 26% engine load, respectively
- Most of the sub 10 nm particles downstream the PMP were formed in the ET of the PMP, because:
 - CPC 3025A had higher concentration than CPC 3776;
 - Particle concentration of those sub 10 nm particles oscillated in relation with the oscillation of the PMP ET temperature.
- The CS showed much less of a tendency to form particles downstream than the APC.





Acknowledgements

CARB

For funding and instruments

Drs. Alberto Ayala and Jorn Herner for encouraging this study

AVL LIST GmbH Inc.

Providing an AVL particle counter and technical support Drs. Barouch Giechaskiel and Richard Frazee, and many other people

UCR/CE-CERT

Mr. Donald Pacocha, Mr. Joe Valdez, Mr. Edward O' Neil, and Zhihua Liu of Contributions in conducting the chassis dynamometer test Drs. Akua Asa-Awuku, David Cocker, and Paul Ziemann

University of Minnesota

Dr. Jacob Swanson for advice