

**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Equipment List**

Component

Manufacturer/Model

Nozzle

Healy Model 900¹
(Figures 1A-1 and 1A-2)

Clean Air Separator

Healy Model 9961 Clean Air Separator
(Figures 1A-3 and 1A-4)
Healy Model 9961H Clean Air Separator
(Figures 1A-3H and 1A-6)

Inverted Coaxial Hoses

Healy Model 75 Series (3/4" I.D.)
(Figures 1A-5, 1A-8 and 1A-9)
75W-XXX-YZYZ

Where

W represents color of hose (varies)

Note: Product label will have an "X" in
this position for all hose colors

XXX represents hose length

First two digits for length in feet

Last digit - length in tenths of foot

Note: Product label will have "XXX" in
this position for hose length

Y represents hose end type

S = Swivel End

F = Fixed End

Z represents thread type

2 = Healy Straight Thread

3 = Metric Thread

4 = Balance-Type Thread

¹ Nozzle can have either a two position or three position hold open clip (see Figure 1A-1).

Component

Manufacturer / Model

**Dispenser Conversion
Adaptors (Optional)²**

Healy Model CX6-A (Required on Gasboy, Global Century,
Reliance and Select Dispensers)

Healy Model CX6-VV1A*

Healy Model CX6-VV2A*

Healy Model CX6-VV3A

EBW Model 303-301-01

(Figures 1A-9 and 1A-10)

Note: Items marked with asterisk (*) are no longer
manufactured, but may be used for dispenser retrofit.

Reconnectable Breakaway Coupling

Healy Model 8701VV

(Figures 1A-11 and 1A-12)

Healy Model 807 Swivel

(Figures 1A-13 and 1A-14)

Flow Limiter³

Healy Model 1301

(Figures 1A-15 and 1A-16)

Healy Model 1302

(Figures 1A-17 and 1A-18)

Dispenser Vacuum Pump

Healy Model VP1000 Vacuum Pump

Healy/Franklin Electric Model VP1000
Vacuum Pump

(Figure 1A-19)

² If optional components are installed or required by regulations of other agencies, the components and model numbers manufactured by Franklin Fueling Systems may be used to facilitate installation. The use of dispenser conversion adaptors not listed above may be used to facilitate installation provided that all applicable performance standards are met.

³ Flow limiter is mandatory when the flow rate is greater than 10.0 gallons per minute to comply with US EPA requirement. 1301 is used with 8701VV breakaway. 1302 is used with 807 swivel breakaway.

Component

Manufacturer / Model

Dispensers

Note: Unihose dispensers shall be required unless as provided by Section 4.10 of CP-201.

Gilbarco Encore Series⁴

Healy Kit VP1000R⁵ or VP1000S⁶

<u>Model #'s</u>	<u>Description:</u>
NAO	Encore 1 Grade Multi-hose
NA1	Encore 2 Grade Multi-hose
NA2	Encore 3 Grade Multi-hose
NA3	Encore 4 Grade Multi-hose
NG0	Encore 3 Grade Single-Hose
NG1	Encore 4 Grade Single-Hose plus 1
NG4	Encore 2 Grade Single-Hose
NJ0	Multi-hose Blender
NJ2	Multi-hose Blender plus 1
NL0 NL1 NL2 NL3	Encore X+1 Blender
NN0 NN1 NN2 NN3	Encore X+0 Blender

GasBoy 9800 Series (Gilbarco)

Healy Kit VP1000M⁷

<u>Model #'s</u>	<u>Description:</u>
9852 – Suffix1 Suffix2	
9853 – Suffix1 Suffix2	

Where:

Suffix1 can be:

A	=	Factory fabrication and assembly modifications to chassis
HC	=	High capacity model
M	=	Manifold supply inlet at the pumping unit inlet
TW1	=	Manifold supply inlet
TW2	=	Two individual supply inlets
X	=	Dispenser supplied by a submersible pump
Q	=	Utilizes an alternate meter and Pump

⁴ Encore Dispensers factory equipped with Healy VP1000 will now have an angled (~13°) outlet casting.

⁵ Kit used to install Healy components in Encore Balance series dispenser. VP1000R previously sold as equivalent to VP1000L.

⁶ Kit used to install Healy components in Encore Assist series dispenser. VP1000S previously sold as equivalent to VP1000K.

⁷ Kit used to install Healy components in GasBoy 9800 series dispenser

Component

Manufacturer / Model

Suffix2 can be:

B	=	Battery back-up for electronics
C	=	Pump Interface
D	=	DC conduit and junction box
F	=	Fuel filter
G	=	Imperial gallons registration
H	=	High hose retriever
I	=	Internal hose retriever
L	=	Lighted panel
N	=	Equipped to handle a long spout nozzle
P	=	Satellite dispenser as part of the unit (for connection to a master pump)
PP	=	Solenoid valves (optional only on pumps)
R	=	Liters registration
S	=	Piping for connection to satellite
SS	=	Stainless steel panels
SSA	=	Equipped with stainless steel doors
SSTS	=	Stainless steel tops and doors
T	=	Mechanical totalizer
U	=	Submersible drive relays
W	=	Heater
Y	=	Vapor recovery ready
Z	=	Front Load Nozzle
2	=	230 VAC/60hz operation
3	=	230 VAC/60hz operation with 380VAC/60hz motor (available on all models except 9852Q)
25	=	230VAC/50hz operation
35	=	230VAC/50hz operation with 380VAC/50hz motor
4	=	RS-485 interface
5	=	50hz operation
7	=	Electronic totalizer activator on both sides
9	=	Provided with 900-R Series TopKat

Component

Manufacturer / Model

A	=	Number of grades 1 = one grade 2 = two grades 3 = three grades 4 = four grades 5 = five grades
B	=	Number of sides 1 = one side 2 = two sides
C	=	Number of columns 1 = one column 2 = two columns

Wayne Vista Series

Healy Kit VP1000T¹¹ & VP1000V¹²

Model #'s Description:
prefix/VXXXYZ/suffix

Where:

Prefix=		Any number or letter
V	=	Vista
X	=	Any digit
Y	=	D or P D = remote dispenser type for delivering fuel P = suction pump for delivering fuel
Z	=	1, 3, 4, 5, 6, 7 or 8
Suffix=		D1 or D2, and any combination of number(s) or letter(s)

Wayne Global Century & Select Series¹³

Model #'s Description
3/GABCDE/Suffix

Where:

A	=	Model Series 2 = Global Century 7 = Select
B	=	Cabinet Style 2 = Column Style

¹¹ Kit used to install Healy components to 3V and 4V Vista series dispenser. VP1000T previously sold as equivalent to VP1000C.

¹² Kit used to install Healy components to 1V and 2V Vista series dispenser. VP1000V previously sold as equivalent to VP1000F.

¹³ Dispenser configuration only available for purchase from Dresser Wayne. There is no Kit for retrofit of these dispenser types.

Component

Manufacturer / Model

C	=	Flow Rate Capacity 0 = Standard Flow 4 = Twin I, Dual Filters
D	=	Number of Hoses & Orientation 1 = Single, Island-Oriented 2 = Twin I, Island-Oriented 3 = Twin II, Island-Oriented 7 = Twin I, Lane-Oriented OR Single Side, Lane-Oriented w/ "R" Suffix 8 = Twin II, Lane-Oriented
E	=	Dispenser Type D = Dispenser-Remote
Suffix	=	Any combination of letters or numbers

Wayne Reliance Series¹⁴

Model #'s
/GABCDE/Suffix

Description

Where:

A	=	Model Series 5 = Reliance Mechanical Fleet – Pricing 6 = Reliance Mechanical Fleet – Volume Only
B	=	Cabinet Style 2 = Column Style
C	=	Flow Rate Capacity 0 = Standard Flow
D	=	Number of Hoses & Orientation 1 = Single, Island-Oriented 2 = Twin I, Island-Oriented 3 = Twin II, Island-Oriented
E	=	Dispenser Type D = Dispenser-Remote
Suffix	=	Any combination of letters or numbers

¹⁴ Dispenser configuration only available for purchase from Dresser Wayne. There is no Kit for retrofit of this dispenser type.

Component

Manufacturer / Model

FFS/Healy Universal Retrofit Manual¹⁵

Healy Kits

VP1000A¹⁶

VP1000D¹⁷

VP1000G¹⁸

VP1000H¹⁹

VP1000J²⁰

Z071V²¹

Z070E²²

Z008²³

Z009²⁴

Table 1
Components Exempt from Identification Requirements

Component Name	Manufacturer	Model Number
Dispenser Kit	Healy	VP1000A & VP1000B VP1000D VP1000G VP1000H VP1000J VP1000M VP1000N VP1000P VP1000Q VP1000R VP1000S VP1000T VP1000V Z008 Z009 Z070E Z071V

¹⁵ Any dispenser not currently listed in Exhibit 1 can be upgraded to Healy EVR using one of the kits listed in this section.

¹⁶ Kit contains Universal Wire Harness for use in any dispenser make or model. For use with any VAC or VDC solenoid valves. VP1000A previously sold as equivalent to VP1000B.

¹⁷ Early Gilbarco Encore 300 Blender Dispensers – 120 VAC valves (mfg. before 04/2003).

¹⁸ Wayne DL Non-Blender Dispensers – 120 VAC valves.

¹⁹ Tokheim Premier C Blender Dispensers – 24 VDC valves.

²⁰ Early Tokheim Blender Dispensers – Combination 120 VAC & 24 VDC valves.

²¹ Universal Vapor Kit.


²² Universal Electrical Kit.

²³ Standard Low Profile Single Hose Dispenser Retrofit Kit.

²⁴ Standard Low Profile Dual Hose Dispenser Retrofit Kit.

**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

Exhibit 1




**Figure 1A-1
Healy Model 900 EVR Nozzle**



**Figure 1A-2
Healy Model 900 Nozzle**

**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Figure 1A-3
Healy Model 9961 Clean Air Separator**



**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

Exhibit 1



**Figure 1A-4
Healy Model 9961 Clean Air Separator**



**Figure 1A-5
Healy Model 75 Series Hose**


Diagram illustrating the installation of a float check valve assembly for a clean air separator. The assembly includes a float check valve (P/N 9466G) and an air breather assembly (P/N 9948).

Labels and Components:

- VENT VALVE (SUPPLIED BY INSTALLER):** Located at the bottom left, connected to the main vent line.
- SUPPORT AIR BREATHER PIPE VERTICALLY WITH THE VENT LINE SUPPORT SYSTEM OR ITS OWN SUPPORT SYSTEM (DETERMINED BY INSTALLER) TO MEET LOCAL CODES.** A vertical support pipe for the air breather.
- AIR BREATHER ASM. AIR (IN/OUT) P/N 9948:** The air breather assembly, positioned 12' MINIMUM ABOVE GRADE.
- PLUG:** Located at the bottom of the air breather assembly.
- FLOAT CHECK VALVE P/N 9466G OVERFILL PROTECTION:** The main float check valve assembly.
- MINIMUM SLOPE 1/8" PER FOOT PITCH TOWARD VENT 100' MAX. LENGTH:** The required slope for the vent line.
- PLUG:** Located at the bottom of the float check valve assembly.
- BALL VALVES LOCKED CLOSED IN NORMAL OPERATION:** Three ball valves (A, B, C) are shown in the closed position.
- BALL VALVE LOCKED OPEN IN NORMAL OPERATION:** One ball valve (D) is shown in the open position.
- BALL VALVE LOCKED CLOSED IN NORMAL OPERATION:** One ball valve (E) is shown in the closed position.
- AIR:** The clean air separator tank.
- VAPOR:** The vapor separator tank.


**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Figure 1A-6
Healy Model 9961-H Clean Air Separator**




**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Figure 1A-7
Hanging Hardware Selection Options
Model 8701VV Breakaway and 1301 Flow Limiter**




**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Figure 1A-8
Hanging Hardware Selection Options
Model 807 Swivel Breakaway and 1302 Flow Limiter**




**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Dispenser Conversion Adaptors**




**Figure 1A-9
Healy Model CX6-A**



**Figure 1A-9
Healy Model CX6-VV1A**




**Figure 1A-9
Healy Model CX6-A**




**Figure 1A-9
Healy Model CX6-VV2A**

**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Dispenser Conversion Adaptors**



**Figure 1A-10
Healy Model CX6-VV3A**



**Figure 1A-10
EBW Model 303-301-01**

**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Healy Model 8701VV Breakaway**




Figure 1A-11



**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Healy Model 807 Swivel Breakaway**

Figure 1A-13





Figure 1A-14




DECALS SHOWN LARGER FOR READABILITY


EITHER LABEL MAY APPLY

**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

Exhibit 1



**Figure 1A-15
Healy Model 1301 Flow Limiter**



**Figure 1A-17
Healy Model 1302 Flow Limiter**




**Figure 1A-16
Healy Model 1301 Flow Limiter**



**Figure 1A-18
Healy Model 1302 Flow Limiter**

**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**

**Exhibit 1
Figure 1A-19
Healy Model VP1000 Vacuum Pump**



**Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD**


**Exhibit 1-Part 2
Vapor Equipment List for Liquid Condensate Trap**

<u>Component</u>	<u>Manufacturer/Model</u>
Riser Adapter	INCON model TSP-K2A (Figure 1A-20)
In-Line Filter	140 micron, Swagelok B-4F2-140 or SS-4F2-140, or equivalent
Screen	Aluminum Insect screen (18X14 mesh), or Stainless Steel Insect screen (18X18 mesh).
Stainless Steel Hose Clamp	Sized to secure screen to suction tube.
Liquid Sensor¹	Must have an audible and visual alarm
Liquid Condensate Trap¹	Any capacity, manufacturer, make and model

¹ Must meet applicable State Water Resources Control Board requirements (e.g. LG-113, LG-167 and LG-169) and any local authority having jurisdiction which includes the Certified Unified Program Agency (CUPA).

Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD

Figure 1A-20
Typical Liquid Condensate Trap Installed Below the Transition Sump



Executive Order VR-201-M
Healy Phase II EVR System
Not Including ISD

Figure 1A-21
Typical Liquid Condensate Trap Installed Inside the Transition Sump

Note: A Liquid Condensate Trap installed inside a liquid AND vapor tight transition sump that is monitored with a liquid sensor can be single walled (if installed before July 1, 2004).

