

## INSTALLATION INSTRUCTIONS for HEALY SYSTEMS, INC. CLEAN AIR SEPARATOR

The Model 9961 or 9961H, Healy Systems Clean Air Separator (CAS) consists of a 400 gallon steel vapor processor vessel that contains a fuel resistant bladder to hold excess gasoline vapors that may develop in gasoline storage tanks during idle periods of gasoline dispensing facility operation. Models and Drawings with a “H” suffix apply to horizontal CAS installations and those without a “H” suffix apply to vertical CAS installations. The CAS assembly weighs approximately 800 pounds which makes it necessary to have a power assisted lifting device available at the installation site to remove the CAS from the transportation vehicle and place it on the required concrete pad (see drawing 9900-9945 or 9900-9945H). The pad (level within 1/8”/foot) is located within 100 feet to the gasoline storage tank vent lines. The pad is a requirement of this installation. **DO NOT PLACE THE CLEAN AIR SEPARATOR DIRECTLY ON THE GROUND OR ASPHALT SURFACE.** NOTICE: The installer is responsible to ensure that the installation meets the latest edition requirements of NFPA 30A, Chapter 10. No electrical connections are required. The CAS securement method shown in drawing 9900-9945 or 9900-9945H shall be approved by the local authority having jurisdiction with respect to wind and seismic loading. Installer shall not loosen, rotate or remove factory installed fittings or flange as this may damage factory seals and void warranty.

In addition to the vapor processor vessel, there is a hardware kit that contains the following:

- 4 Locking 1” NPT Ball Valves
- 4 Pad locks (keyed alike)
- 1 Breather Assembly, Healy Model 9948
- 1 Float Check Valve Assembly, Model 9466G

Reference the appropriate Healy Systems installation drawing (9900-9942, 9900-9942H, 9900-9971, 9900-9971H, 9900-9972, 9900-9972H, 9900-9973 or 9900-9973H of this manual) for placement of the above parts for the vent stack configuration required by the local Authority Having Jurisdiction (AHJ) for the Underground Storage Tank (UST) system. **A flexible connection between the Clean Air Separator and the vent line(s) is allowable if required by the local Authority Having Jurisdiction (AHJ) to meet seismic requirements. Should the flex connection be installed such that it is not supported, the slope of the flex connection shall be greater than the 1/8”/foot slope required for the rest of the one inch galvanized piping.** The local contractor is responsible to provide all necessary, galvanized piping, non-hardening, UL classified pipe joint compound and plumbing fittings. Additional Pressure/Vacuum (P/V) vent valves to complete installation are not included in the hardware kit. Healy is not responsible for the warranty of any other P/V vent valve purchased to complete installation.

The CAS arrives at the site assembled and tested. All plumbing shall be done using 1” galvanized steel pipe (Schedule 40) and approved nipples, as called out in the installation drawing appropriate for the site installation. Mounting hardware shall be galvanized or stainless steel. Careful attention must be paid to the installation drawing appropriate for the site installation to assure proper operation of the bladder system. Do not inflate the bladder assembly after installation.

It is important that the CAS be secured to the concrete pad as shown in drawing 9900-9945 or 9900-9945H of this manual to prevent any unintentional repositioning of the CAS as the connecting plumbing to the vent system is accomplished.

Franklin Fueling Systems  
3760 Marsh Road  
Madison, Wisconsin 53718 USA  
ARB Approved Installation, Operation and Maintenance Manual

Website: <http://www.franklinfueling.com>  
Email: [sales@franklinfueling.com](mailto:sales@franklinfueling.com)  
Telephone: 800-225-9787  
Fax: 608-838-6433



## OPERATION AND PURGING

### NORMAL OPERATION:


- ❑ There are four ball valves on the CAS. Each ball valve is to be installed so as to allow opening and closing with nothing obstructing the full range (90°) of movement. In normal operation, only the valve (A) at the top of the CAS shall be open – the other three valves (B, C and D) shall be closed. All four valves shall be locked in the above positions. The two plugs (E and F) should be installed using a non-hardening, UL classified pipe joint compound and tightened to 60 ft-lbs.

### DRAINING THE BLADDER:

- ❑ Any liquid coming over from the vent system would have collected above the valve (A) in the riser pipe before going into the bladder. An inspection of the need to drain the bladder is easily made by removing the plug (E) at the tee on the bottom plumbing of the CAS. Before removing this plug, open the valve (B) above the tee to release any liquid into the piping below. Wait approximately 30 seconds and then close the valve (B). Now, remove the plug (E) at the tee on the bottom plumbing of the CAS – be sure to have a container suitable for gasoline available to catch fluid. If liquid in excess of 16 ounces (473 ml) drains out, the bladder should also be drained.
- ❑ Should it be necessary to drain the bladder:
  1. Close the upper ball valve (A) (usually open) leading to the gasoline storage tank vent lines.
  2. Open the valve (C) that goes to the internal syphon tube. Be sure the other three ball valves (A, B and D) that connect to the vent lines and CAS are closed.
  3. Remove the plug (E) from the bottom tee and connect an explosion proof evacuation pump capable of handling liquid. Have a liquid tight, container suitable for gasoline positioned to receive any fluid that may exit the system and start the pump. If no liquid returns within 30 seconds, the bladder is dry – discontinue pumping, remove the pump, replace the plug (E) and return the ball valves to their normal, locked, positions.

### DRAINING THE CAS:

- ❑ Should it be necessary to drain the CAS (between the bladder and steel wall):
  1. Close the ball valve at the top (A) of the CAS and also the two valves (B and C) on the vertical risers.
  2. Remove the plug (E) in the bottom tee and place a metal container below the pipe opening.
- ❑ Carefully open the ball valve (D) at the bottom of the CAS – observe that the container that is being drained into does not overflow – empty container as required until fluid no longer comes from the pipe when the valve is open.
  1. Close the ball valve (D) and replace the plug (E) into the tee.
  2. Return all ball valves to their normal locked positions.




The information disclosed herein is the property of Franklin Fueling Systems, Inc. Neither the drawing nor the information disclosed herein is to be reproduced, stored in a retrieval system, or used or disclosed to others by any person, except as specifically authorized in writing by Franklin Fueling Systems, Inc. This drawing shall be returned to Franklin Fueling Systems upon request.

MATERIAL:	
DO NOT SCALE DIMENSIONS	XX ± .02
STANDARD NOT DIMENSIONS (UNLESS OTHERWISE SPECIFIED)	XXX ± .005
SPECIAL DIST.	ANGULAR ± 1/2°

TITLE		DATE	
CLEAN AIR SEPARATOR MOUNTING SLAB DETAILS		07/31/02	
DRAWN BY: JWH		DATE: 07/31/02	
APPROVED BY: [Signature]		DATE: 07/31/02	
SCALE: 1/8"		SHEET: 1 OF 1	

DRW NO: 9900-9945





**NOTICE**


DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.

INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.

DWG NO: 9900-9942


The information contained herein is the property of Franklin Fueling Systems, Inc. and is to be used only for the project and site identified herein. No other use or reproduction is permitted without the express written consent of Franklin Fueling Systems, Inc.	
<b>REVISED</b>	
15 10/20/08	10/20/08
14 08/28/08	08/28/08
13 08/28/08	08/28/08
12 08/28/08	08/28/08
11 08/28/08	08/28/08
10 08/28/08	08/28/08
9 08/28/08	08/28/08
8 08/28/08	08/28/08
7 08/28/08	08/28/08
6 08/28/08	08/28/08
5 08/28/08	08/28/08
4 08/28/08	08/28/08
3 08/28/08	08/28/08
2 08/28/08	08/28/08
1 08/28/08	08/28/08





The information contained herein is the property of Franklin Fueling Systems, Inc. and is to be used only for the specific application and equipment for which it is intended. It is not to be used for any other purpose without the written consent of Franklin Fueling Systems, Inc.	
M/REV# TO NOT SCALE DRAWING (FRANKLIN FUELING SYSTEMS) (SHALL THROUGH DIMENSIONS) SCALE 1/2"	DATE 05/23/07 9900-9942 H
REV# 05/23/07 9900-9942 H	DATE 05/23/07 9900-9942 H





- NOTE:
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE FULCRUM FEATURE.
  - 2 - FULCRUM FEATURE CONTROL-NO ELECTRICAL POWER REQUIRED.
  - 3 - AIR BREATHER MUST BE INSTALLED AT A MINIMUM HEIGHT OF 1/2" ABOVE GRADE ON 1" PIPE.
  - 4 - VENT LINE TIE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT POSITION.
  - 5 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS.
  - 6 - HOLES TO SLOPE SLIGHTLY TOWARD CONDENSATE DRAIN. FITCH SLAB WITHIN 1/8" INCH/FOOT TOWARD DRAIN. FITCH SLAB WITHIN 1/8" INCH/FOOT TOWARD CONDENSATE DRAIN END OR SHAW HOLES FOR PROPER DRAINAGE.
- △ - RETAIN CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE IF REQUIRED BY THE LOCAL AUTHORITY HAVING JURISDICTION (M.A.) TO MEET SEISMIC REQUIREMENTS. SHOULD THE FLEX CONNECTION BE INSTALLED SUCH THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPE.

NOTICE  
 DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.  
 INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FACTORY INSTALLED FITTINGS OR FLANGE AS THIS MAY DAMAGE FACTORY SEALS AND VOID WARRANTY.


By a Representative, authorized Signatory, of the Manufacturer, Franklin Fueling Systems, Inc., 14100 S. 10th Street, Suite 100, Tukwila, WA 98168, the undersigned hereby certifies that the information furnished herein is true and correct to the best of the undersigned's knowledge and belief, and that the undersigned is duly qualified to make such a statement.


DATE	02/22/07
BY	9900-9971
REVISED DATE	06/09/07
NO. OF SHEETS	1 OF 1

REV	7	DATE	06/09/07	BY	9900-9971
REV	6	DATE	06/09/07	BY	9900-9971
REV	5	DATE	06/09/07	BY	9900-9971
REV	4	DATE	06/09/07	BY	9900-9971
REV	3	DATE	06/09/07	BY	9900-9971
REV	2	DATE	06/09/07	BY	9900-9971
REV	1	DATE	06/09/07	BY	9900-9971

Franklin Fueling Systems, Inc.  
 CLEAN AIR SEPARATOR HORIZONTAL INSTALLATION (VENT VALVE)







- NOTE:
- 1 - ALL BALL VALVES (B.V.) TO BE UL LISTED AND HAVE PASSLOCK FEATURE.
  - 2 - PIPING REQUIRED TO BE INSTALLED AT A MINIMUM HEIGHT OF 12" ABOVE GRADE ON 1" PIPE.
  - 3 - VENT LINE TE IN CAN BE INSTALLED ANYWHERE ALONG THE VENT STACK LINE PROVIDED THAT PIPE SLOPE IS MAINTAINED AND THE CHECK VALVE IS IN THE CORRECT VERTICAL INSTALLATION.
  - 4 - ONLY GALVANIZED PIPE IS TO BE USED FOR PIPING CONNECTIONS.
  - 5 - HOOKS TO SLOPE SLIGHTLY TOWARD CONDENSATE DRAIN. PITCH SLAB WITHIN 1/8" INCH/FOOT TOWARD VESSEL DRAINAGE.
  - 6 - A REMOVABLE CONNECTION BETWEEN THE CLEAN AIR SEPARATOR AND THE VENT LINE(S) IS ALLOWABLE PROVIDED THE VENT LINE(S) IS SUPPORTED VERTICALLY TO MEET SENSIC REQUIREMENTS. THAT IT IS NOT SUPPORTED, THE SLOPE OF THE FLEX CONNECTION SHALL BE GREATER THAN THE 1/8" PER FOOT SLOPE REQUIRED FOR THE REST OF THE ONE INCH GALVANIZED PIPING.

NOTICE  
 DRAWINGS ARE TWO DIMENSIONAL REPRESENTATION OF TYPICAL CLEAN AIR SEPARATOR (CAS) INSTALLATION. ACTUAL CAS INSTALLATIONS WILL VARY SLIGHTLY FROM THE REPRESENTATION SHOWN.  
 INSTALLER SHALL NOT LOOSEN, ROTATE OR REMOVE FLEXIBLE FITTINGS OR FLANGES AS THIS MAY CHANGE FACTORY SEALS AND VOID WARRANTY.

This manufacturer's standard warranty covers only the material and workmanship of the product. It does not cover the product's performance or the results of its use. The user must read and understand the instructions and warnings. The manufacturer is not responsible for any damage or injury resulting from the use of the product.	
DATE: 08/22/07 DRAWN BY: 9900-9973 CHECKED BY: H	TITLE: CLEAN AIR SEPARATOR HORIZONTAL INSTALLATION (3) VENT VALVES PROJECT NO: 9900-9973 SCALE: N.T.S. SHEET 1 OF 1

REVISIONS: 1 (HARD COPY) 08/22/08 2 (HARD COPY) 08/22/08	DATE: 08/22/08 DRAWN BY: 9900-9973 CHECKED BY: H
----------------------------------------------------------------	--------------------------------------------------------